PARTS LIST

for

KitchenAid®

6 QT. STAND MIXER

PROFESSIONAL 600 BOWL LIFT

MODELS:

KP26M1XMR4 (Meringue)
KP26M1XBS4 (Blue Steel)
KP26M1XCM4 (Cinnamon)
KP26M1XDP4 (Dark Pewter)
KP26M1XLC4 (Licorice)
KP26M1XMC4 (Metallic Chrome)
KP26M1XNP4 (Nickel Pearl)
KP26M1XPM4 (Pearl Metallic)
KP26M1XBP4 (Brass Pearl)
KP26M1XBR4 (Bronze Pearl)
KP26M1XCE4 (Copper Pearl)

KP26M1XRC4 (Cayenne)
KP26M1XSV4 (Silver Sage)
KP26M1XSE4 (Seashell)
KP26M1XAZ4 (Azure Blue)
4KP26M1XMR4 (Meringue)
4KP26M1XBS4 (Blue Steel)
4KP26M1XDP4 (Dark Pewter)
4KP26M1XLC4 (Licorice)
4KP26M1XMC4 (Metallic Chrome)
4KP26M1XNP4 (Nickel Pearl)
4KP26M1XPM4 (Pearl Metallic)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



KITCHENAID ST. JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

For Models: KP26M1X__4, 4KP26M1X__4




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COLOR VARIATION PARTS

For Models: KP26M1X__4, 4KP26M1X__4

Coloro Subject To Change	
Any Color Not Listed is 970867 Any Color Not Listed 970872 Dark Pewter 9708730 Blue Steel 9708730 Blue Steel 9708730 Blue Steel 9709770 Pearl Metallic Chrome 970874 Nickel Pearl 9709173 Dark Pewter 9709173 Metallic Chrome 970876 Nickel Pearl 9709173 Bronze Pearl 970918 Pearl Metallic Dark Pewter 970918 Pearl Metallic 9709173 Bronze Pearl 970918 Pearl Metallic 970871 Dark Pewter 9709321 Silver Sage 9709331 Pearl Not Pewter 970873 Blue Steel 970874 Blue Steel 970874 Blue Steel 970875 Nickel Pearl 970977 Pearl Metallic Chrome 970873 Blue Steel 970874 Blue Steel 970874 Blue Steel 970874 Blue Steel 970875 Nickel Pearl 9709180 Bronze Pe	ell n vter Chrome earl earl eearl ge ue oot y el n vter Chrome earl earl earl earl

CASE, GEARING AND PLANETARY UNIT For Models: KP26M1X__4, 4KP26M1X__4




CASE, GEARING AND PLANETARY UNIT For Models: KP26M1X_4, 4KP26M1X_4

Illus. No.	Part No.	DESCRIPTION
1	*0*	Gearcase Motor Housing
2	9707507	Motor (10 Tooth) Cap, Attachment
4	9707983 9709194	Hub Pearl Nickel Thumb Screw Black
5 6	9709196	Grey Band, Trim Power Cord
7	9706551 9706552 9703671	
8		Control Assembly (Incl. Knob)
9	9706648 9706649 9703312	Black Knob Gray Knob
10 11 12 13 14 15	9706090 9703434 9707627 9703438 9708191	Washer
16	16897	Bearing, Lower Center
17 18 19	9709231 9707223 9706529	Gear, Worm
20	9703338	Gear, Attachment Hub Bevel
21 22 23 24	9703337 3400617 3400814	Gear, Bevel
25 27 28	9703680 3400200	Clip, Retaining
29 30 31	9703560 9703570 9703445 67500–55 9707425	Front Rear Bearing, Thrust "O" Ring
32	9706036	Lead, Motor To Control
33	9706247	
34 35	9703339 9704677	Gear, Internal

**Refer To Page 3 Color Variation Parts

BASE AND PEDESTAL UNIT

For Models: KP26M1X__4, 4KP26M1X__4



ACCESSORY PARTS For Models: KP26M1X__4, 4KP26M1X__4

Illus. No.	Part No.	DESCRIPTION
	4164778	Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer, (RVS-A) (FPP-A)
	4164749	Food Grinder (FG-A)
	8211924	Grain Mill (KGMA)
	4164768	Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A)
	4164775	Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP)
	4164750	Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder Coarse Shredder, Thick Slicer, And Thin Slicer (RVS-A)
	4164824	Pasta Maker Plates (SNP-A)
	4164774	Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A)
	4162838	Food Tray (FT)
	4164748	Juicer (JE)
	4164747	Can Opener (CO)
	4164803	Sausage Stuffer Kit (SSA)
	9707963	Ice Cream Maker (KICAOWH0)
	4160588	Grease, Planetary